

```
I1 = imread("/Users/Harsh/Documents/GSU_Spring/ComputerVision/
Harsh_Assignment_3/Q3/image1.jpeg");
I2 = imread("/Users/Harsh/Documents/GSU_Spring/ComputerVision/
Harsh_Assignment_3/Q3/image2.jpeg");
```

```
% Convert to grayscale.
I1gray = im2gray(I1);
I2gray = im2gray(I2);
```

```
figure
imshowpair(I1,I2,"montage")
title("I1 (left); I2 (right)")
```



```
figure
imshow(stereoAnaglyph(I1,I2))
title("Composite Image (Red - Left Image, Cyan - Right Image)")
```

Composite Image (Red - Left Image, Cyan - Right Image)



```
% collect interest points  
blobs1 = detectSURFFeatures(I1gray,MetricThreshold=2000);  
blobs2 = detectSURFFeatures(I2gray,MetricThreshold=2000);
```

```
figure  
imshow(I1)  
hold on  
plot(selectStrongest(blobs1,30))  
title("Thirty Strongest SURF Features In I1")
```

Thirty Strongest SURF Features in I1



```
figure
imshow(I2)
hold on
plot(selectStrongest(blobs2,30))
title("Thirty Strongest SURF Features In I2")
```

```
% extract features
[features1,validBlobs1] = extractFeatures(I1gray,blobs1);
[features2,validBlobs2] = extractFeatures(I2gray,blobs2);
```

```
indexPairs = matchFeatures(features1,features2,Metric="SAD", ...  
    MatchThreshold=5);
```

```
matchedPoints1 = validBlobs1(indexPairs(:,1),:);  
matchedPoints2 = validBlobs2(indexPairs(:,2),:);
```

```
% matched points  
figure  
showMatchedFeatures(I1, I2, matchedPoints1, matchedPoints2)  
legend("Putatively Matched Points In I1","Putatively Matched Points In I2")
```



Error using error

The message must be specified as either a character vector, string scalar, or a message structure.

```
[fMatrix, epipolarInliers, status] = estimateFundamentalMatrix(...
    matchedPoints1, matchedPoints2, 'Method', 'RANSAC', ...
    'NumTrials', 10000, 'DistanceThreshold', 0.1, 'Confidence', 99.99);

if status ~= 0 || isEpipoleInImage(fMatrix, size(I1)) ...
    || isEpipoleInImage(fMatrix, size(I2))
    error(['Either not enough matching points were found or '...
        'the epipoles are inside the images. You may need to '...
        'inspect and improve the quality of detected features '],...

```



```

        'and/or improve the quality of your images.']);
end

inlierPoints1 = matchedPoints1(epipolarInliers, :);
inlierPoints2 = matchedPoints2(epipolarInliers, :);

figure;
showMatchedFeatures(I1, I2, inlierPoints1, inlierPoints2);
legend('Inlier points in I1', 'Inlier points in I2');

```



```

% rectify images

```

```
[tform1, tform2] = estimateStereoRectification(fMatrix, ...  
    inlierPoints1.Location,inlierPoints2.Location,size(I2));
```

```
[I1Rect, I2Rect] = rectifyStereoImages(I1,I2,tform1,tform2);  
figure  
imshow(stereoAnaglyph(I1Rect,I2Rect))  
title("Rectified Stereo Images (Red - Left Image, Cyan - Right Image)")
```

Rectified Stereo Images (Red - Left Image, Cyan - Right Image)



```
% cvxRectifyImages("parkinglot_left.png","parkinglot_right.png");
```